


SECTION III. ASSEMBLY & INSTALLATION INSTRUCTIONS CON'T.

Model ADK & DDK Conveyor Angle Adjustment

(Fig. 33)



“Adjustment Points”

To achieve the many angles of incline on EMI Model ADK and DDK Conveyors, it is necessary to use both the adjustment on the legs and the adjustment slides on the sub-base. Between both adjustment points you should be able to achieve the proper discharge belt height for your application. (Fig. 33)