

## Sensor Bracket for >ASS< Quick Changer

- Sensor bracket mounts on the Robot or EOAT-Side of Quick Changer.
- Sensor signals when QC lock is engaged.
- Does not provide mechanical locking.



### Sensor Bracket for >ASS< Quick Changers

**NEW**

Quick#	Part#	>ASS< #	Description	Price
3843	SWH-SH-G-50	1-024-05-00	for Small Size QC (50mm)	\$25.20
3844	SWH-SH-G-90150	1-024-09-00	for Standard & Large Size QC's (90mm & 150mm)	\$25.20

### Inductive Sensors

Quick#	Part#	Description	Price
2429	GSG-IS-NPN	NPN Ø4mm N.O. Inductive Sensor, 2m long	\$62.00
2430	GSG-IS-PNP	PNP Ø4mm N.O. Inductive Sensor, 2m long	\$62.00

